

## Video Switcher Time Settings

### I. Connect the Devices

Connect the computer and video switcher to the same network. You can use a router or a direct connection. You can connect in the following ways.

**Method A)** When connecting device with a router with DHCP features.

The matrix switcher will auto obtain an IP address, so you can scan the device directly by the control software.


**Method B)** When connecting video switcher with a PC without DHCP.

Please make sure that device and PC are in the same local area network, and set PC's IP address to "192.168.1.xxx", except device's default IP address 192.168.1.215, then press the "scanning" button on control software to scan the device. If the device cannot be found, wait 30s and then scan again.

### II. Synchronization Time

A. Set the computer time to the time zone you want to set

B. Click the sync button and wait 20 seconds.



C. Time synchronization is successful if the time of the video switcher is consistent with the current computer time.